

## TYRE SPREADER



NHT775

### **Standard features:**

Apply to tire	145-275
Voltage	110V 50/60HZ 220V 50/60HZ
Air Pressure	6-10 KG/C <sup>2</sup> O

### **Other SPECIFICATIONS:**

The Air Powered Tire Spreader (With Standing Base) is designed for tire fix and spread when repairing the passenger tires .The available operations include tire inspecting, cutting, buffing, and dust suctioning, inserting tubes and patching.

The wider platform offers a more stable work surface. The adjustable light increases visibility inside the tire .A ll makes the repairing work more quick and convenient.