

KOLB CONCEPTLINE EASY

More than just a layout machine



Illustration similar

Kolb Design Technology GmbH & Co. KG

Josef-Wallner-Straße 5 a, 94469 Deggendorf, Germany
Phone +49 (0)991 344739-0, Fax +49 (0)991 344739-290
sales@kolb-technology.com, www.kolb-technology.com



Member of



STREICHER Group

KOLB CONCEPTLINE EASY

More than just a layout machine

**3 axes layout machine for Clay-Styling Studios;
suitable for measuring / digitalizing of design models**

Machine data

Mechanical construction / drive systems:

- Combination of mineral cast and high quality fabrication, filled with vibration absorbing material
- Linear guides
- X / Y – axes: linear drive
- Z – axis: ball screw drive

Height: 3,628 mm (incl. rail: 3,960 mm)

Weight: 1,078 kg (without rail)

Electrical

connection: TNS, 400 V/16 A/50 Hz/3 PH/PE

Power: 1.5 kVA

Travel speed: 12 m / min

Additional product information

- CMM measuring probe and 3-D accessories
- Different options for intuitive motion control available: control tablet, handbox, 6 axes module
- Customised measuring functions integratable
- Different safety options available
- Individual studio concepts can be realized (flexible rail length, duplex installation, double floor, turn table/lifting table and model supports integratable)

Travel range and measuring box (rail length 8,000 mm)

	Travel range (in mm)	Measuring box (in mm)
X-axis	6,724	6,724
Y-axis	1,624	1,624
Z-axis	2,440	2,440